

How to Plug in your PC

To Mouse




To Older Style Printer





Ethernet Cable
Looks like an extra large phone cable and connects to HS Modem Or Router

To Power Bar
Or Wall Receptacle



To Telephone
Wall Jack
This jack is usually labelled "LINE" or has a picture of a wall jack



To Telephone
This jack is usually labelled "PHONE" or has a picture of a phone

To Keyboard
Looks the same as mouse, coloured pink or purple



To Speakers
Usually GREEN



To Monitor
Three rows of pins



USB Cable can go to
Scanners, Printers, Digital
Cameras, Mp3 Players



22 Saskatchewan St. W.
Moose Jaw, Stock
S6H 2S7

v: 692-6774
f: 692-6122
e: intrex@sasktel.net
w: intrex.ca